



WOODTRENDS[®]
BY SOUND SEAL

TIMBER-STIX™

INSTALLATION INSTRUCTIONS:

DIRECT WALL INSTALLATION
WITH ADHESIVE

1. Measure the height and width of the area you'll be covering with Timber-Stix panels.
2. If required, cut panels to size.
 - Use a circular saw to cut the panels to height.

TIP: Applying masking tape on the wood surface prior to cutting can help prevent splintering or splitting.

 - Use a utility knife or equivalent to cut the panels to width by cutting through the black PET backing.
3. After cuts are made, reattach the Timber-Stix to the black PET backing with screws or staples of appropriate length, working from the backside of the panel.
4. Installation can commence. Lay each Timber-Stix panel face down and apply Liquid Nails, 3095 Carpet Glue adhesive or similar.

NOTE: Adhesive typically has 20-25 minutes of working time.
5. Position Timber-Stix on the wall and press firmly.
6. Secure Timber-Stix to the wall temporarily with screws at top, bottom and midpoints while the construction adhesive dries.

NOTE: Screws should be applied through the black PET felt and NOT the Stix. Doing so could cause spitting or splintering of the product.

TIP: Maintain even spacing and avoid visible seams using the built-in shi lap.
7. Repeat the process until you achieve desired coverage.

TIP: If required, cut edges may be concealed with finish trim or decorative molding supplied by others.