



WOODTRENDS®
BY SOUND SEAL

TIMBER-STIX™

INSTALLATION INSTRUCTIONS: FURRING STRIP WALL INSTALLATION

1. Measure the height and width of the area you'll be covering with Timber-Stix panels.
2. Install furring strips every 24" on center. The framework created should run perpendicular to the length of Timber-Stix panels.
3. If required, cut panels to size.
 - Use a circular saw to cut the panels to height.

TIP: Applying masking tape on the wood surface prior to cutting can help prevent splintering or splitting.

 - Use a utility knife or equivalent to cut the panels to width by cutting through the black PET backing.
4. After cuts are made, reattach the Timber-Stix to the black PET backing with screws or staples of appropriate length working from the backside of the panel.
5. Installation can commence. Position and secure Timber-Stix to the furring strips with screws placed 12" on center horizontally and 24" on center vertically at the furring strip locations.

NOTE: Screws should be applied through the black PET felt and NOT the Stix. Doing so could cause spitting or splintering of the product.

TIP: Maintain even spacing and avoid visible seams using the built-in shiplap.
6. Repeat the process until you achieve desired coverage.

TIP: If required, cut edges may be concealed with finish trim or decorative molding supplied by others.

NOTE: Furring strips can be omitted if the wall surface is capable of supporting a direct screw attachment. Assess your space and follow the installation instructions most appropriate for your circumstances and skill level.