

WoodTrends by Sound Seal Maintenance & Care of WoodTrends Ceiling & Wall Panels

WoodTrends acoustical and non-acoustical panels are manufactured with high quality wood veneers and engineered wood components, and therefore should be cared for as all quality architectural wood products are. It is extremely important that the humidity and temperature kept within the recommended guidelines. See warranty for exact information.

When cleaning, panels should be vacuumed with a non-marring, natural bristle head. Avoid using a short or hard bristle cleaning heads as damage can occur. After removing the dust, you should restore the woods beauty by wiping the panels with a quality furniture polish such as lemon oil. Do not spray the polish directly onto the panel. Instead, apply the polish to a soft, dust free cloth and wipe the panels lightly. At all costs, avoid using water or a damp cloth as this may affect the stability of the veneer surface.

The intervals of cleaning will depend on the conditions of your building. We recommend cleaning the panels at least once a year but as noted your building conditions may require more or less frequent cleanings to keep up the natural beauty of our product.