

# Superfloor® Installation Instructions for Carpet & Carpet Tile Flooring



## Prep Work

- Failure to follow installation instructions could result in voided warranty
- Floor moisture level should not exceed 3%
- If relative humidity is over 75%, product should not be installed

1. Inspect concrete sub floor for any open cracks and fill with high-grade epoxy filler. Remove any excess concrete lumps or residue that may interfere with the installation of the underlayment.

## Wood Floor

Sub floor should be properly sloped, structurally sound, level, and clean. Good grade plywood that does not exceed deflection of L/360 of span including live and dead loads should be used.

The Superfloor® sound reducing underlayment consists of soft impact absorbing boards. Small irregularities in the sub floor (up to 2mm), are leveled out perfectly by Superfloor®.

2. Superfloor® tiles must acclimatize in their sealed packaging, in the room where they are installed for at least 48 hours, at a temperature of at least 65° F (Fig. A). Before starting your installation of Superfloor® make sure the sub floor is permanently dry, and clean, (no dust).

## Tools needed for installation

- Utility Knife
- Stapler & Staples

## Installation Instructions

Superfloor® tiles must be installed tight to each other with the long edges parallel to the direction of the light. (Fig. B)

### Glue Down Carpet:

When carpet is to be glued to the Superfloor® tiles, the Superfloor® sheets have to be glued to the sub floor.

### Loose Lay Carpet Tiles:

Carpet tiles can be installed on Superfloor® without glue. This must be done in such a way that the joints of the carpet tiles are staggered against those of the Superfloor® tiles to as great an extent as possible. (Fig. C)

### Stretched Carpet:

Superfloor® tiles are very suitable for use with carpet tack strips. Install tack strips, staple Superfloor® to sub floor, use no more than 2-3 staples per Superfloor® tile. Stretch the carpet onto the carpet strips. (Fig. D)

